




Wi-AP210-Lite

1. Packing Content



1 x AP



4 x Plastic Anchor



4 x Self-Tapping Screws




1 x Ethernet Cable



1 x Quick Installation Guide

2. Appearance Overview

• Wi-AP210-Lite



• LED indicator


| LED Indicators | Status | Description |
|------------------|-------------|---|
| System Indicator | Green light | Fast Blinking: The system is starting. Solid On: The system is working normally. |
| LAN Indicator | Yellow | The LAN port is connected via Ethernet cable |
| | Off | The LAN port is disconnected. |

• Port and Button


| Port&Button | Description |
|-------------|--|
| RESET | Reset button, which is used to restore the factory. Holding down the reset button for 10 seconds to revert to factory settings. |
| WAN/PoE | 10/100Mbps Base-T Ethernet Port, which supports 802.3af PoE Input. If the AP is powered through PoE, please connect this port to the PoE switch supporting 802.3af output. It is generally connected to the upstream switch. |
| LAN | 10/100Mbps Base-T Ethernet port. It is generally connected to wired LAN devices such as PC. |
| DC | DC Input: 12V, 0.5A. The AP is powered through 12V DC Input. |

3. Typical Connection

• Bypass mode topology




• AC Gateway mode topology




4. Device Installation

• Ceiling Mounting

- 1. Place the bracket in the center of the ceiling and then mark the positions for the screw holes and the position for Ethernet cable.




- 2. Drill holes in the marked positions using a hammer drill




• Power via PSE Device

- The APs can be powered via PoE switch which supports 802.3af PoE output.



• Power via Power adapter


- Some APs can be powered via power adapter which supports 12V DC output.



5. Power Supply


• Power via PSE Device

- The APs can be powered via PoE switch which supports 802.3af PoE output.



• Power via Power adapter

- Some APs can be powered via power adapter which supports 12V DC output.



6. Configuration Method

Method 1. Connect computer to the wireless signal of AP, the default SSID is "Wi-Tek xxxx". Password is 88888888



Method 2. Connect computer to the AP by Ethernet cable.



Step 1. On the computer, please set the static IP under the same subnet with AP, 192.168.1.xx



Step 2. Please launch a browser such as Google Chrome or Firefox, type 192.168.1.88 into address bar and click on enter to get in the login page of wireless access point. The default login password is "admin".


*Login device




Step 3. After get in the management page, On the left side menu, please go to [Wizard] to setup the access point

6. Configuration Method


Method 1. Connect computer to the wireless signal of AP, the default SSID is "Wi-Tek xxxx". Password is 88888888



Method 2. Connect computer to the AP by Ethernet cable.



Step 1. On the computer, please set the static IP under the same subnet with AP, 192.168.1.xx



Step 2. Please launch a browser such as Google Chrome or Firefox, type 192.168.1.88 into address bar and click on enter to get in the login page of wireless access point. The default login password is "admin".

*Login device



Step 3. After get in the management page, On the left side menu, please go to [Wizard] to setup the access point

7. Cloud management settings

Step 1. Launch your web browser then enter http://cloud2.wireless-tek.com into address bar and click on enter to get in the login page of wireless access point.



Step 2. Register an account password by user name or email.



Step 3. Log in to the cloud account with the account password after registration.



Step 4. Select the appropriate operation mode and follow the instruction of wizard to finish the settings. If already exist a Router in your network, please choose, Fit AP mode; if not, you can choose Wireless Router mode Notice: If you do a reset, AP will recovery to Fit AP mode



• Fit AP Mode default Login IP: 192.168.1.88 admin/admin



• Wireless Router Mode default Login IP: 192.168.1.1 admin/admin



8. FAQ

Q1. The LED is not lit.

- A1: Please check the PoE switch is 802.3af/at.
- A2: Make sure the PoE switch is outputting the correct voltage.
- A3: Make sure the Ethernet cable does support PoE function.

Q2. What can I do if the login window does not appear?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q3. How can I connect to the cloud management page?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q4. How can I reset the AP?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q5. How can I update the AP firmware?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q6. How can I change the AP name?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q7. How can I change the AP password?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q8. How can I change the AP SSID?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q9. How can I change the AP channel?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q10. How can I change the AP power?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q11. How can I change the AP antenna?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q12. How can I change the AP antenna?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q13. How can I change the AP antenna?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q14. How can I change the AP antenna?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q15. How can I change the AP antenna?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Warranty Card

| | |
|-------------------|--|
| Username | |
| Address | |
| Telephone No. | |
| Purchase Shop | |
| Purchase Address | |
| Product Model No. | |
| Purchase Time | |
| Serial No. | |
| Dealer Signature | |

8. FAQ

Q1. The LED is not lit.

- A1: Please check the PoE switch is 802.3af/at.
- A2: Make sure the PoE switch is outputting the correct voltage.
- A3: Make sure the Ethernet cable does support PoE function.

Q2. What can I do if the login window does not appear?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q3. How can I connect to the cloud management page?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q4. How can I reset the AP?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q5. How can I update the AP firmware?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q6. How can I change the AP name?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q7. How can I change the AP password?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q8. How can I change the AP SSID?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q9. How can I change the AP channel?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

Q10. How can I change the AP power?

- A1: Please check if the computer is the static IP 192.168.1.xxx.
- A2: Please try another browser.
- A3: Reboot your AP device and try again.
- A4: Disconnect the Internet connection and try again, after login, connect to the internet.

